

FULL VERSION MANUAL SEEK 450 RECHARGE



PRODUCT OVERVIEW

The packaging contains the following parts:

- Lamp unit Headband
- Integrated battery
- Quick Guide
 Charging cable not included

BEFORE USE

CHARGE THE INTEGRATED BATTERY

- Tilt the front of the lamp unit forwards to expose the charging port. Connect a USB-C charging cable to the charging port.
- Connect the other end of the charging cable to a USB-port (either from a power bank or a USB charger/adapter connected to a wall outlet).
- Beneath the charging port, there is an LED that shows the battery status during charging:
- Red light = battery is charging
 Green light = battery is fully charged

Approximated charging time (depending on input source): 2 h

Note! When the battery is fully charged the charger automatically switches to maintenance mode. Note! Never leave a lamp unattended during charging.

Note! The charging port is water resistant, but make sure there are no debris inside the port when inserting the cable.

ADJUST THE HEADBAND

The elastic headband with anti-slip rubber on the inside is designed to give a comfortable fit at all times. Adjust the headband by moving the sliding buckles to fit it onto your head.

On the top of the lamp unit there is a push button which controls all light modes. This button can be locked to prevent the lamp from being lit by accident.

To activate the button lock; make sure the lamp is turned OFF, press the button with an extra long press (3 sec). A small red LED inside the lens will start flashing (not to be confused with the main red LED/red light mode that will also light up briefly). When the small red LED stops flashing and lights constantly and the main red LED turns off - the button is locked.

If you try to start lamp with button lock activated the small LED will flash red to indicate that

To deactivate the button lock; press the button with an extra long press (3 sec). The small red LED will start flashing. After 3 seconds, when the button lock is deactivated, the small LED will turn steady green. Now you can start the lamp as normal.


DURING USE

SWITCH ON YOUR HEADLAMP

The push button on the top of the lamp controls all light modes.



LONG PRESS



In addition to white light, Seek 450 offers a red light mode that preserves your night vision.



Seek features Silva Intelligent Light which combines a long reach spot light with a close flood light. The lamp head is tiltable to give you the right light, exactly where you need it

BATTERY STATUS INDICATION

When the headlamp is turned off, a small LED inside the lens is turned on to indicate the battery status. This indication will be on for 3 seconds.

- Green light Battery in good condition
- Red Battery needs charging



SEEK 450 RECHARGE Stormy Sky: 38553 Mountain Mist: 38554 Midnight: 38552 Whiteout: 38530

AFTER USE

To make sure you get maximum performance from your headlamp, clean it regularly with a

ABOUT LI-ION BATTERIES

The lamp has an internal Li-ion battery and should be stored in a dry environment within the temperature range of -30°C and +60°C. If you would like to store your lamp for a longer period (more than 30 days) the battery should not be fully charged. Recommended charge level for storing is 30%. You can always charge a half full battery without damaging its characteristics. Do not expose the lamp to extreme temperatures which may cause fire or explosion. To get the most out of your battery - do not expose the lamp to low temperatures during use. Do not disassemble or mistreat the lamp unit; risk for chemical burn.


TECHNICAL SPECIFICATIONS

See matrix below Lumen / Burn time / Light distance: Weight: Battery type 70 g (2.5 oz) Li-lon 1.35 Ah / 3.85 V, integrated

Charging time:
Water resistance:
Operative temperature range: IPX5

-30 - (+)50°C -40 - (+)60°C Storage temperature range:

PERFORMANCE:



PROTECTING THE ENVIRONMENT.

Lamp unit, batteries and packaging are recyclable. Please dispose these items at designated recycling stations.

Silva warrants that your Silva headlamp for a period of five (5) years* will be free from defects in materials and workmanship under normal use. Rechargeable batteries are covered for 2 years or 300 charge cycles. Silva's liability under the warranty is limited to repairing or replacing the product. This limited warranty applies only to the original purchaser. If the product is found to be defective during the warranty period, please contact the original place of purchase. Make sure to have your proof of purchase handy when returning the product. Returns cannot be processed without the original proof of purchase

This warranty does not apply if the product has been modified or if it has not been installed. used, repaired or maintained in accordance with instructions from Silva. The warranty also does not apply if the product has been subjected to abnormal physical or electrical use or in case of negligence, abuse or accident. The warranty also does not cover normal wear and tear. Silva is not responsible for any consequences (direct or indirect) or damages arising from the use of this product. Under no circumstances will Silva's liability exceed the amount you paid for the product. Some jurisdictions do not allow the exclusion or limitation of inci-dental or consequential damages, so the above limitation or exclusion may not apply to you.

The warranty is only valid and may only be processed in the country of purchase. The consumer's rights pursuant to law of the country of purchase are not affected by this warranty.

- * Headlamp: Five (5) years
- * Rechargeable battery: Two (2) years or 300 charge cycles.

For more information please visit www.silvaweden.com